

SAN REMO II



DETOMASO

GRATULATION ZUM ERWERB DEINER DETOMASO UHR!

Ein Roadtrip durch Italien, die Hände fest am Lenkrad und den sanften Fahrtwind spüren – dieses Gefühl verkörpert deine neue Uhr.

Du bist jetzt Eigentümer eines Zeitgebers, der sich durch hohe Präzision und innovatives Design auszeichnet. Inspiriert von klassischen Sportwagenlegenden und dem Lebensgefühl Italiens, stehen DETOMASO Uhren für ein bisschen Retro und ganz viel Charakter.

Damit wir gewährleisten können, dass deine neue Uhr viele Jahre problemlos funktioniert, lies bitte sorgfältig die folgende Bedienungsanleitung. So erinnert dich deine DETOMASO Uhr stets daran, deinen ganz eigenen Takt zu finden: LIVE THE MOMENTUM.

MATERIALIEN

Erst das Zusammenspiel von mutigen Ideengebern, erstklassigen Uhrmachern und ambitionierten Designern haben aus der Idee hinter DETOMASO Präzisionsarbeit werden lassen. Und diese Ambitionen spiegeln sich auch in den ausgesuchten Materialien wider.

DETOMASO verwendet nur beste Komponenten für die SAN REMO II:


Japanisches Quarz Markenuhrwerk von Miyota Kaliber 2115 mit Datumsanzeige

Gehäusematerial aus antiallergenem 316L Chirurgenstahl

Kratzfestes Saphirglas

30 ATM Wasserdichtigkeit nach DIN 8310

LIVE THE MOMENTUM



PFLEGEHINWEISE

Deine Uhr soll dir viel Freude bereiten und dich lange begleiten. Schütze deine Uhr vor Stößen, Magnetfeldern, starker Hitze und Chemikalien sowie vor mechanischem Abrieb. Mit einer Wasserdichtigkeit von 30 ATM kannst du deine Uhr sogar beim Schwimmen und Tauchen tragen. Beim Tragen sollte die Krone immer in eingedrückter Position sein.

Muss die Batterie gewechselt werden, kannst du gerne von unserem Wartungsangebot Gebrauch machen und deine Uhr in unsere Uhrmacherwerksatt einsenden (Kontakt: service@detomaso-watches.com). Du kannst deine Batterie aber auch im Fachgeschäft austauschen lassen.

Solltest du Kondenswasser unter dem Glas sehen, muss die Uhr unverzüglich in unsere Uhrmacherwerkstatt gesendet oder ins Fachgeschäft gebracht werden, damit die Feuchtigkeit keinen Schaden anrichtet.

EINSTELLUNG DER UHRZEIT

Ziehe die Krone heraus, in die 2. Position.

Drehe die Krone im Uhrzeigersinn, um die Stunden- und Minutenzeiger zu bewegen.

Drücke anschließend die Krone wieder in die Normalposition.

EINSTELLUNG DES DATUMS

Ziehe die Krone heraus, in die 1. Position.

Drehe die Krone gegen den Uhrzeigersinn, um das Datum einzustellen. Dabei musst du beachten: Wenn das Datum zwischen 21.00 Uhr abends und 01.00 Uhr morgens gestellt wird, wechselt das Datum am folgenden Tag nicht.

Drücke anschließend die Krone wieder in die Normalposition.

DETOMASO CUSTOMER SERVICE:

DETOMASO
c/o Temporex Lifestyle GmbH
Hinsbecker Löh 10
45257 Essen / Germany
+441603976950
service@detomaso-watches.com
www.detomaso-watches.com/eu



CONGRATULATIONS ON YOUR NEW DETOMASO WATCH!

Hop in the car, cruise the highway, and keep life moving. DETOMASO watches embody the desire to rediscover your freedom.

You are now the owner of a watch that stands out for its high precision and innovative design. The idea is based on the Italian lifestyle and the big idols of classic automobile design in the 70s. A little retro, and a lot of character.

To ensure that we can guarantee the functionality of your watch for many years, please read the following operating instructions carefully. Your DETOMASO watch is a continuous reminder that you create your own path in life – LIVE THE MOMENTUM.

MATERIALS

DETOMASO started as an ambitious idea between a visionary designer and a world-class watchmaker, but has quickly transitioned to a precision timepiece. And these ambitions are reflected in the selected materials.

DETOMASO uses only the best components for the SAN REMO II:

Movement: Miyota Japanese Quartz Caliber 2115 with date

Case material: Anti-allergenic 316L surgical steel

Glass: Scratch-resistant sapphire glass

Water resistance: 30 ATM/300M/1000FT


CARE INSTRUCTIONS

Your watch should accompany you for a long time. Protect your watch from shocks, magnetic fields, strong heat and chemicals, as well as mechanical abrasion. With a water resistance of 30 ATM, you can even wear your watch while swimming and diving. The crown should always be in the depressed position when being worn.

If your watch stops, you should first change the battery.

This can be done by our watchmaker (contact: service@detomaso-watches.com) or in any jewelry shop.

In the event of condensation under the glass, the watch should immediately be sent to the DETOMASO watchmaker, or taken to a specialist shop in order to prevent damage from the moisture.



SETTING THE TIME

Pull out the crown to the 2nd position.

Turn the crown clockwise to move the hour and minute hands.

Then push the crown back to the pushed-in position.

SETTING THE DATE

Pull out the crown to the 1st position.

Turn the crown counter-clockwise to set the date. If the date is set between 9pm and 1am, the date does not change on the following day.

After the date has been set, push the crown back into the pushed-in position.

DETOMASO CUSTOMER SERVICE:

DETOMASO
c/o Temporex Lifestyle GmbH
Hinsbecker Löh 10
45257 Essen / Germany
+441603976950
service@detomaso-watches.com
www.detomaso-watches.com/eu

Clients from the US please contact:

DETOMASO
c/o Zeitgeist Inc.
3600 Horizon Drive
Suite 110
King of Prussia, PA 19406 USA
service@detomasowatches.com
(215) 999-4010
www.detomasowatches.com

